



Cabinet Size

Wall Cabinet




Wall High 30"-1 Door

W0930,W1230,W1530,
W1830,W2130




Wall High 30"-2 Door

W2430,W2730,W3030,
W3330,W3630




Wall High 36"-1 Door

W0936,W1236,W1536,
W1836,W2136




Wall High 36"-2 Door

W2436,W2736,W3636,
W3336,W3636




Wall High 42"-1 Door

W0942,W1242,W1542,
W1842,W2142




Wall High 42"-2 Door

W2442,W2742,W3042,
W3342,W3642




Wall Blind Corner Cabinet

W2730,W2736,W2742




Wall Bridge Cabinet 2 Door

W3012,W3015,W3018,W3021,
W3024,W3612,W3615,W3618,
W3621,W3624




Wall Diagonal Corner

WDC2430,WDC2436,
WDC2442




Wall Dish Rack

WPR3015,WPR3615




Wall End Shelf

WEA0930,WEA0936,
WEA0942



Wall Microwave


WMC2730,WMC2736,WMC2742,
WMC3030,WMC3036,WMC3042



Wall Wine Rack


WWR3015,WWR3615

Base Cabinet




Base Blind Cabinets

(BBC36/42, BBC45/45)




Base Cabinet 1- Door

(B09,B12,B15,B18,B21)




Base Cabinet 2-Door

(B24,B27,B30)




Base 2-Door,2Drawer

(B33,B36)




Base End Shelf

(BES09L,BES09R,ES12L,ES12)




Base Lazy Susan

(BLS33,BLS36)




Sink Base

(SB33,SB36,SB42)




Spice Rack

(BSR06,BSR09,BSR12)



Three Drawer Base


(DB12,15,18,21,24,30,36)



Base Microwave Cabinet


BMC30

Tall Cabinet




Oven Cabinets -Double

OC3184,OC3190,OC3196




Oven Cabinets -Single

OC3184S,OC3190S,
OC3196S

Pantry -Single Door


PC1884,PC1890,PC1896




Pantry -Double Door

PC2484,PC2490,PC2496,PC3
084,PC3090,PC3096


Vanity Cabinet




Vanity Drawer Base

VDB12,VDB15,VDB18,
VDB21

Vanity Sink Cabinet


OC3184S,OC3190S,
OC3196S

Vanity Cabinet With Drawers

VSD3021L,VSD3021R,VSD362
1L,VSD3621R,VSD4221L,VSD
4221R

Vanity Double Sink Cabinet

VCD6021



Vanity Single with Drawer

VSD6021

Accessories




Base Filler-Fluted

OC3184,OC3190,OC3196



Base Filler


OC3184S,OC3190S,
OC3196S

Corbel

PC1884,PC1890,PC1896




Crown Molding


PC2484,PC2490,PC2496,PC3
084,PC3090,PC3096

Deco Door

OC3184,OC3190,OC3196



Dishwasher Panel

OC3184S,OC3190S,
OC3196S




Glass Holder

PC1884,PC1890,PC1896



Island Skin Panel

PC2484,PC2490,PC2496,PC3
084,PC3090,PC3096



Light Rail Molding

Outside Corner Molding

Pantry Skn Panel



Roll Out Tray

OC3184,OC3190,OC3196

OC3184S,OC3190S,
OC3196S

PC1884,PC1890,PC1896

PC2484,PC2490,PC2496,PC3
084,PC3090,PC3096



Scribe Molding

Outside Corner Molding

Trash Can Slider -Single

Trash Can Slider -Double

OC3184,OC3190,OC3196

OC3184S,OC3190S,
OC3196S

TR-15"

TR-18",TR-21"



Wall Filer & Tall Filer

WF330,WF336,WF342,WF63
0,WF636,WF642,TF396,TF69

6

